

18. Ignition System



Service Information	18-1	Ignition Coil	18-8
System Location	18-2	Ignition Pulse Generator Inspection	18-9
Troubleshooting	18-4	Ignition Pulse Generator Removal/ Installation	18-10
Ignition System Inspection	18-6	Ignition Timing	18-11

Service Information

- When checking the ignition system, always follow the steps in the troubleshooting flow chart (page 18-4).
- The digital transistorized ignition system uses an electrically controlled ignition timing system. No adjustments can be made to the ignition timing.
- A rough diagnosis can be made by identifying the cylinder whose spark timing is incorrect.
- The ignition control module (ICM) may be damaged if dropped. Also, if the connector is disconnected when current is flowing, the excessive voltage may damage the unit. Always turn off the ignition switch before servicing.
- A faulty ignition system is often related to poorly connected connectors. Check those connections before proceeding.
- Make sure the battery is adequately charged. Using the starter motor with a weak battery results in a slower engine cranking speed as well as no spark at the spark plugs.
- Use spark plugs of the correct heat range. Using spark plugs with an incorrect heat range can damage the engine. Refer to section 2 of the Common Service Manual.
- For neutral switch inspection, refer to section 25 of the Common Service Manual; for switch location, see page 18-2 or 18-3 of this manual (System Location).
- For the ignition switch and engine stop switch inspection, check for continuity on the continuity chart of the Wiring Diagram (section 22). Refer to page 21-4 for side stand switch inspection.



System Location

Standard Model



ABS/TCS or LBS-ABS/TCS Model


ABS/TCS model shown:



Troubleshooting

No spark at all plugs (Faulty input system)

- If there is no spark at all plugs, the problem could be at the input of the ignition system (ignition pulse generator, power input circuit of the ignition control module (ICM), neutral switch, side stand switch or ICM).



No spark at either ignition group

- If there is no spark at either group, the problem is suspected in the primary coil side of the ignition system (ignition coil, or ignition control module (ICM) and ignition coil circuit).

Switch the ignition coil primary terminal connection between the faulty pair and good pair. Try spark test again.

"No Spark" condition shifts to other pair

"No Spark" condition remains with faulty pair

Remove the faulty pair ignition coil and check the ignition coil resistance (page 18-7).

- Faulty ignition coil
- Faulty spark plug wire

Measure resistance of the ignition primary coil at ICM connector (page 18-6).

Abnormal

- Poor or loose contact of ignition coil 3P mini connector
- Open circuit between the ICM and ignition coil

Normal

- Faulty ICM

No spark at one plug (Trouble in secondary coil side)

- Faulty spark plug is most likely.

Replace (suspected bad spark plug) with known good spark plug and conduct spark test.

Normal

- Original spark plug no good.

Abnormal

Put the spark plug wire on and measure resistance of ignition secondary coil (page 18-7).

Normal

Conduct spark test on good ignition coil.

Abnormal

Normal

Remove the spark plug wire, and measure the resistance of the ignition secondary coil (page 18-7).

Abnormal

- Faulty ignition coil

Normal

- Poor contact of spark plug wire
- Faulty spark plug wire

Side stand switch does not function at all.

Side Stand Indicator: Check the side stand indicator for function.

Normal

- Faulty side stand switch
- Open circuit in Green/White or Green wire

Abnormal

Side Stand Switch: Check the side stand switch for continuity.

Normal

- Loose or poor contact of related connectors
- Open or short circuit in wire harness
- Burnt indicator bulb

Abnormal

- Faulty side stand switch

Ignition System Inspection

NOTE

- Check the system components and lines step-by-step according to the troubleshooting chart on pages 18-4 and 18-5.


Standard model:

Remove the left fairing pocket (page 2-6).

Remove the ignition control module (ICM) from the stay, disconnect the ICM connector and check it for loose or corroded terminals.

STANDARD MODEL:

(1) ICM




ABS/TCS or LBS-ABS/TCS model:

Remove the middle fairing inner cover (page 2-7).

Disconnect the TCS/ignition control module (ICM) 16P connector and check it for loose or corroded terminals.

ABS/TCS or LBS-ABS/TCS MODEL:

(1) TCS/ICM



Measure the data between the connector terminals using the following chart.


Item		Terminals	Standards (20°C/68°F)
Battery voltage input line		Black/white [ABS/TCS or LBS-ABS/TCS model: Black/Yellow] (+) and Ground (-) with the engine stop switch RUN (Standard model) and the ignition switch ON.	Battery voltage should register
Ignition pulse generator line		Yellow and White/yellow	405–495 Ω
Ignition primary coil line	No. 1,3	Yellow/blue and Black/white	2.16–3.19 Ω
	No. 2,4	Blue/yellow and Black/white	
Neutral switch line		Light green and Ground	Continuity in neutral No continuity in any gear
Side stand switch line		Green/white and Ground	Continuity with the stand up No continuity with the stand down
Ground line		Green and Ground	Continuity
Tachometer line		Yellow/green and Green wire connector of the harness side at the instruments	Continuity

Ignition Coil

Inspection


Remove the upper fairing (page 2-9).
Disconnect the ignition primary coil 3P connector (white) and measure the primary coil resistance between each ignition coil.

Primary coil resistance:
Standard: 2.16–3.19 Ω (20°C/68° F)




Disconnect the spark plug caps from the plugs and measure the secondary coil resistance with the spark plug caps in place.

Standard: 22.5–27.5k Ω (20°C/68° F)



If the resistance is out of the range, remove the spark plug caps and measure the resistance between the secondary coil terminals

Standard: 13.5–16.5k Ω (20°C/68° F)



Ignition Pulse Generator Inspection

NOTE

- It is not necessary to remove the ignition pulse generator to make this inspection.

Standard model:

Remove the right side cover (page 2-2).

ABS/TCS or LBS-ABS/TCS model:


Remove the top shelter (page 2-5).

Disconnect the ignition pulse generator 4P connector and measure the resistance between the White/Yellow and Yellow wires.

Standard: 405—495Ω (20°C/68°F)


Refer to page 18-9 for ignition pulse generator replacement.

STANDARD MODEL:




(1) IGNITION PULSE GENERATOR 4P CONNECTOR

ABS/TCS or LBS-ABS/TCS MODEL:



(1) IGNITION PULSE GENERATOR 4P CONNECTOR

Ignition Pulse Generator Removal/Installation

















Requisite Service

- Fuel tank Removal/Installation (page 2-12).

Procedure	Q'ty	Remarks
Removal Order		Installation is in the reverse order of removal.
(1) Oil pressure switch terminal	1	At installation, insert the neutral switch wire into the clamp as shown.
(2) Neutral switch connector	1	
(3) Waterproof connector (4P)	1	
(4) Bolt	4	
(5) Gasket	1	
(6) Dowel pin	2	
(7) Bolt	2	
(8) Ignition pulse generator	1	

Symbols

The symbols used throughout this manual show specific service procedures. If supplementary information is required pertaining to these symbols, it would be explained specifically in the text without the use of the symbols.

	<p>Replace the part(s) with new one(s) before assembly.</p>
	<p>Use special tool</p>
	<p>Use optional tool. Use the same procedure you use to order parts.</p>
 10 (1.0, 7.2)	<p>Torque specification. 10 N·m (1.0 kg-m, 7.2 ft-lb)</p>
	<p>Use recommended engine oil, unless otherwise specified.</p>
	<p>Use molybdenum oil solution (mixture of the engine oil and molybdenum grease in a ratio of 1 : 1).</p>
	<p>Use multi-purpose grease (Lithium based multi-purpose grease NLGI #2 or equivalent)</p>
	<p>Use molybdenum disulfide grease (containing more than 3% molybdenum disulfide, NLGI #2 or equivalent) Example: Molykote® BR-2 plus manufactured by Dow Corning, U.S.A. Multi-purpose M-2 manufactured by Mitsubishi Oil Japan</p>
	<p>Use molybdenum disulfide paste (containing more than 40% molybdenum disulfide, NLGI #2 or equivalent) Example: Molykote® G-n Paste manufactured by Dow Corning, U.S.A. Honda Moly 60 (U.S.A. only) Rocol ASP manufactured by Rocol Limited, U.K. Rocol Paste manufactured by Sumico Lubricant, Japan</p>
	<p>Use silicone grease</p>
	<p>Apply a locking agent. Use a middle strength locking agent unless otherwise specified.</p>
	<p>Apply sealant</p>
	<p>Use brake fluid, DOT 3 or DOT 4. Use the recommended brake fluid, unless otherwise specified.</p>
	<p>Use Fork or Suspension Fluid.</p>